Quick Start



LG Xpression



Find More Information

On The Web

Interactive web tutorials are available at **att.com/ Tutorials** or directly from your device's browser bookmarks. Select Manufacturer: **LG** and Model: **Xpression** from the drop-down menus. Detailed support information including device specifications, user manual, troubleshooting, and user forums are available at **att.com/ DeviceSupport**. For information about your wireless account, service plan or network, visit **att.com/Wireless**.

On The Phone Call AT&T Customer Care at 1-800-331-0500 or dial 611 from any AT&T mobile phone for assistance with your service or device.

Find Accessories

Accessories for productivity, convenience, and fashion are available at **att.com/WirelessAccessories**.



Bluetooth Headset



Custom Cases



Vehicle Power Charger

LG and the LG logo are registered trademarks of LG Electronics, Inc. The *Bluetooth®* word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc. and any use of such marks is under license. © 2012 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies. All other marks contained herein are the property of their respective owners. Some features and services involve charges. Coverage not available in all areas.

Printed in China MBM63622602 (1.0)

Getting to Know Your Phone



Note: For more information on your device, visit **att.com/tutorials**.

Touchscreen and Navigation

Navigation Tips

- To select an item, lightly tap it with your fingertip.
- Use quick flicks of your finger on the touchscreen to scroll up/down and left/right.
- The Notification Bar at the top of the screen includes new message, email, and voicemail notifications. You can also access the music player, enable *Bluetooth*[®], set alarms, and change your ringtone preferences. Tap the bar to see full details. Press the **End Key** or tap the bar to close it.
- C Phone: Access the dialer, call log, and contact list.
- 📇 Address Book: Access your contact list.
- Messaging: Access your text message inbox.
- 🚼 Menu: Open the Main Menu.





Set Up Your Phone

Install the SIM Card and Battery

- ① Lift off the back cover via the notch at the bottom of the cover.
- Ide the SIM card into the SIM card holder with the gold contacts facing downward.
- ③ Insert the battery by aligning the gold contacts on the phone and the battery.
- ④ Replace the back cover.

Install a Memory Card

- Turn off the phone before inserting or removing a memory card.
- ② Remove the back cover.
- ③ With the gold contacts facing downward, slide the memory card into the slot until it clicks into place.
- ④ Replace the back cover.



Customizing Your Phone

Add a Widget

- From the home screen, tap
- ^② Tap and drag a widget to the home screen.
- ③ To remove a widget, drag it back down to the widget bar.
- 4 Tap 🔽.

Add a Favorite Contact

- From the home screen, swipe right to move left to the Contacts home screen.
- Iap and then tap Add.
- ③ Tap a contact name to select the contact as a favorite.
- ④ Tap Add and then tap Done.

Add a Shortcut

- From the home screen, swipe left to move right to the Shortcut home screen.
- 🛛 Tap 🗖.
- ③ To remove a shortcut, tap X next to it.
- To add a shortcut, tap Add and then tap + next to the desired shortcut.
- ⑤ Tap Done.





Calling and Voicemail

Make a Call

- From the home screen, tap
- ② Enter the number you want to call or start spelling the name of the desired contact. You will see a list of contact options. Tap to expand the list.
- ③ Tap a contact and then tap **Call** to place the call.

Access Voicemail

- 1 From the home screen, tap 🔇.
- ② Tap and hold the 1 Key.
- ③ Follow the voice prompts to listen to messages.
- ④ Enter a passcode, if applicable.



Camera

Take a Picture

- From the home screen, press
 Camera Key.
- ② Rotate the device to landscape view.
- ③ Tap the screen and then tap to adjust settings such as white balance and shot mode.
- 🕘 Tap 👈.
- When you're ready, press the Camera Key or tap to take a picture.

Send a Picture

- After taking a picture, tap
 Image: After taking a picture and taking
- ② Tap Message.
- ③ Slide open the QWERTY keyboard and enter a message.
- ④ Tap Send To.
- ⑤ Tap a recipient's name.
- Tap Send.









AT&T Address Book

To Activate Address Book

- From the home screen, tap
- When you first access your Address Book, you will be asked if you want to sync your phone with AT&T Address Book. Tap Yes.
- ③ Tap OK.

To Add Contacts

- 1) From the home screen, tap 📇.
- ② Tap Add New.
- ③ Slide open the QWERTY keyboard and enter the contact's information.
- ④ Tap Save.





Note: Visit att.com/addressbook to access your AT&T Address Book online.

AT&T Services



🚳 AT&T Code Scanner

Access product information by scanning QR, Data Matrix, or UPC codes.



🚯 AT&T Navigator®

Get traffic updates, GPS navigation, and turn-by-turn driving directions on your mobile phone with AT&T Navigator.

AT&T FamilyMap

Locate a family member's wireless phone on a map from your mobile phone or PC.



🔰 myAT&T

Quickly manage your AT&T account, review purchases and downloads, and even make a payment from one easy-to-access menu.

yp YPmobile[®]

Search businesses and popular categories, get ratings and reviews on restaurants, and get the scoop on local deals, right on your mobile phone!

Note: For more AT&T apps, visit the AppCenter. Data usage and subscription charges may apply.





Music and Entertainment

- You can listen to music in the background while performing other tasks. From the home screen, tap the Notification Bar.
- ② Tap Music Player.
- ③ Tap a song to play it.
- 🕘 Tap 🛃 .
- ⑤ You can edit contacts, browse the Web, and more. To exit the music player, return to the home screen and tap Off.



Music Player

AT&T AppCenter®

Access the AppCenter

- From the home screen, tap :::.
- 2 Tap 📶.
- ③ Tap AppCenter.
- ④ You can search for an app or browse all apps by category.
- ⑤ Tap an app to view product information and cost.
- Follow on-screen instructions to download the app.

Access Applications

- From the home screen, tap :::.
- ② Tap <u></u>.
- ③ Tap App Manager.
- ④ From here, you may access applications or tap Shop AppCenter to purchase new ones.





Bluetooth[®] Pairing

- ② Tap 0.
- ③ Tap Bluetooth.
- ④ Tap Search New Device.
- 5 Tap Yes to enable Bluetooth.
- Tap the name of the device you wish to pair with. You may need to enter a passcode.*
- ⑦ Tap Yes twice to connect to the device.



Mobile Web

- From the home screen and with the keyboard open, press the S Browser Key.
- 🛛 Tap 🗖.
- ③ Tap the Web Address field and enter an address.
- ④ Tap **Go To**.
- ⑤ To add a bookmark, tap
- ⑥ Tap Bookmarks.
- ⑦ Tap This Page.
- Image: Tap Save.







Text and Picture Messaging

- ① From the home screen and with the keyboard open, press the Message Key.
- ② Enter a message with the QWERTY keyboard.
- ③ To add a picture, tap Insert.
- ④ You can choose from existing photos in your album or take a new picture. Tap an option and follow on-screen instructions to add the file.
- ⑤ Tap Send To.
- [®] Tap a recipient's name.
- ⑦ Tap Send.

Please don't text and drive.



Þ	Insert			
lov	Picture	Take New Picture) Audio	Record New Audio
l	Video	Record New Video	Slide	O More
		Clos		

Pay-per-use charges apply unless you have a messaging plan.

AT&T Social Net

- From the home screen and with the keyboard open, press the AT&T Social Net Key.
- ② Review and accept the Terms of Use and Privacy Policy.
- ③ Follow the on-screen instructions to manage the social network of your choice.

Access Social Networks and Information

- Tap **f**, **y**, or **m** to quickly update your status.
- Tap 📻 for the latest news and information.

