
ELITE
M488
USER MANUAL



CONTENTS

Introduction phone keys	- 4 -
Introduction widgets	- 4 -
Information Function	Error! Bookmark not defined.
Contact Features	- 7 -
Call History Features	- 9 -
Paste the text / copy Features.....	- 9 -
E-mail Features	- 10 -
Desktop Features	- 12 -
Delete the desktop icon	- 17 -
Music Function.....	- 17 -
FM function.....	- 18 -
Bluetooth Function	- 20 -
Wifi Features	- 20 -
Flight mode Function	- 21 -
Black unlock	- 22 -
Restore to factory default	- 22 -
Storage Settings	- 23 -
English language switching phone	- 23 -
Replacement mobile phone input method	- 24 -
Introduce cross-screen display.....	- 25 -
Browser Features	- 25 -
Q/A.....	- 27 -
1. How to turn off the software running in the background too much.....	- 27 -
2. How to quickly set up Email	- 27 -
3. How do I view the capacity of SD card case.....	- 27 -
4. How to save electricity.....	- 27 -
5. How to lock screen, to prevent others from using.....	- 27 -
6. Why does not the USB data cable links your computer.....	- 28 -
7. How to install a program on a non-Android Market	- 28 -
8. In browsing the web or other applications, how to switch to other applications-	28 -
9. How to enter the silent mode quickly	- 28 -
10. How to forward SMS / MMS	- 28 -
11. How to paste and copy text.....	- 28 -
12. In the phone program group is installed too many applications, how to solve-	28 -
13. Contacts are sorted, can change	- 28 -
14. Contacts whether to support the group	- 28 -
15. Contacts and SMS storage capacity limits the number of.....	- 29 -
16. How to set the SD card, personalized ring tones.....	- 29 -
17. How to sync the phone contacts to the original.....	- 29 -
18. How to use the access Wifi (WLAN)	- 29 -
19. How to Find Contact.....	- 29 -

20. How do I delete the downloaded software.....	- 29 -
21. How to view mobile phone version information.....	- 29 -
22. How do I copy SIM card contact information.....	- 29 -
23. Why the message has a different time and date display	- 30 -
24. Whether to support the Java.....	- 30 -
25. How to open developer options.....	- 30 -
26.Gestures.....	- 30 -

Introduction phone keys

Menu button: Click on the menu button to display the sub-menu functions;

Home button: Click on the Home button to close the current application and enter the main home screen; Note that using this key will not really exit the application, the application will continue to run in the background;

Back button: Click the Back button to go back to a previously navigated page;

Introduction widgets


1. Add widgets to the main screen: Press on the widget or application you wish to move to the main screen for about 3 seconds. Keeping your finger on the widget, drag it onto the main screen.



2. Change the order of widgets: In the main screen, press a widget for about 3 seconds, sliding the widget to change the order of how it's presented on the screen

3. Delete widgets: In the main screen, press a widget for about 3 seconds. On the top of the main screen, you will see "Remove". Slide the widget upwards to delete.




Changing SMS Ringtone

Go to “Settings”  → “Sound & notification” → “General” → “Phone Ringtone” and select the ringtone





View sender information

Go to the message icon  → open the message → click the contact icon




to view the sender's information




Forwarding Messages

Go to the message icon 🗨️ → open the message → press down for 3 seconds on the message you want to forward → a “Message options” box will pop up → select “Forward” and type the name or number you want to forward the message to





View information details

Go to the message icon 🗨️ → open the message → press down for 3 seconds on the message you want to forward → a “Message options” box will pop up → select “View details”




Deleting Sections of a Message

Go to the message icon  → open the message → press down for 3 seconds on the message you want to forward → a “Message options” box will pop up → select “Delete”




Contact Features

Includes all saved contacts groups, contacts and favorites feature;
Arranged by numbers first, then letters (A-Z)





Favorites Introduction

Includes all contacts that call often, as well as their default contact information






Contact Search

Go to Contacts screen → click  button → type the contacts name and the contacts name will appear at the top of the screen





Call History Features

Go to the Call log  → click the menu button → select “delete” → choose the calls to be deleted




Store Contacts from Call Log

Go to the Call log screen  → History tab → click on the contact to be saved → click “Create new contact” → choose whether to save the contact on the phone or on the SIM and save the new information



Copy/Paste Text

Go to the area that is to be copied and press down for 3 seconds → select the area to be copied by either “cut”, “copy”, “share”, or “select all”. To paste, repeat the steps and select “paste” into the area



E-mail Features

Configuring e-mail account

Enter the Program Group screen – Select "Email" application -Enter e-mail address and password

If the system automatically recognizes the mailbox information, will automatically configure; if the system does not recognize, will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.


Gmail For example:

E-mail Address: chinapalms01@gmail.com

Password: chinapalms01


Configure multiple email accounts

Enter the Program Group screen - Select "Email" application -" Click on the menu button-select setting function -select "Add Account" feature




Delete email account

Enter the Program Group screen – Select "Email" application - Click on the menu button-select setting function –select account - select the "Remove Account" function




Email check frequency setting

Enter the Program Group screen – Select "Email" application - Click on the menu button-select setting function –select account - select Sync frequency" function



Desktop Features

The Desktop will include all applications downloaded onto your device, as well as preinstalled applications.





Wallpapers

To change the wallpaper, go to Settings → Display → Wallpaper and choose the wallpaper from your gallery or from the preset wallpapers provided


Application Packet

In the desktop space – sliding the application to another application – click the application to open New Folder




Change the folder name

Open the folder on the desktop - " click Input box - Rename Folder



Change wallpaper

Slide it to the edit control page, choose the wallpaper option,



Add a shortcut to the desktop

Slide it to the edit control page, choose the add option, The Add screen, click the application icon you want to the target page




Add contacts to your desktop

In the widgets space -long press the contact widget -" choose a contact



Add URL to the desktop

In the widgets space -long press the Bookmark widget -" choose a bookmark



Delete the desktop icon


Slide it to the edit control page, choose the arrange option ,then the shortcuts converted to delete state, which you want to delete ,click on the upper left corner of the delete icon



Music Function


Play music

Music player into the main interface, select the song you want to play,



Switch the display mode


The default is the grids shows that if you want to switch to the list shows, left to enter the Options menu, select list mode



FM function


Open radio

Enter radio interface, click the switch button, turn on the radio



Search Channel

Enter the Options menu, select the search channel, and enter the search channel interface





Switch to Speaker

FM player interface, enter the Options menu, choose speakers play





Bluetooth Function

Select "Settings" -" Select "Bluetooth" function




Wifi Features

Select "Settings"- "Select Wi-Fi"- click




Flight mode Function

Select "Settings"- "Select More"- " choose "Flight Mode"function




Or select the phone, "Off" button - "select the "Flight Mode "function





Black unlock

Select "Settings"- Select "security" - Select the "Screen lock" Pattern




Restore to factory default

Select "Settings"- Select "Backup & reset" - select "Factory data reset"





Storage Settings

Select "Settings"- Select "storage"



English language switching phone

Select "Settings"- "Language & input "- Select "Language ", select English or other





Input set

Select "Settings"- " Language & input "-click




button




Replacement mobile phone input method

Select "Settings"- " Language & input "-Default



Introduce cross-screen display

Select "Settings"->"Display "- Check "Auto- rotate screen" according to the phone automatically change the direction of rotation




Browser Features

Visit the website

Browser - Click URL input area" - Enter the URL of web browsing-click




button




Download Web page images or other objects

Browser - "browse the web, long press on the picture, there shortcut keys, choose "Save Image "function



Browser settings / search page

Browser - "browse the web -"click "menu button",-select settings / find on page



Q/A

1. How to turn off the software running in the background too much

Download Advanced Task Manager Advanced Task Manager and select install, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, To free up memory space, reducing the CPU's operation long pressure, increase speed, to extend the purpose of standby time.

2. How to quickly set up Email

In the Android system, can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password; if not automatically fit in the mailbox, the mailbox will be required by user Server information. See details in front of the "E-mail Features" section.

3. How do I view the capacity of SD card case

Select the "Settings"-Select Storage -select "SD card and phone memory", will see the current SD card capacity information phone

4. How to save electricity

First, reduce the screen brightness can be used in peacetime by reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;

Close GPS global positioning, in the "Settings" and select "location services" -uncheck the following "Enable GPS satellite set" can be;

Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;

Usually close calls and text messages to remind vibration;

5. How to lock screen, to prevent others from using

In the "Settings", select " Security "and then select "screen lock" "pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

6. Why does not the USB data cable links your computer

Confirmed in the phone's "Settings"->"Developer options"- in the "USB debugging" functionality check; also installed the correct USB driver

7. How to install a program on a non-Android Market

Select "Settings"- "Security ", the "unknown source" function

8. In browsing the web or other applications, how to switch to other applications

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

9. How to enter the silent mode quickly

In addition to continuing foreign long press the volume down key, and directly into the status bar select the silent mode.

10. How to forward SMS / MMS

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

11. How to paste and copy text

Into the input field - "input string, long press and enter the region, there shortcut keys - "select All" "cut All", "copy All", "paste All"

12. In the phone program group is installed too many applications, how to solve

In the desktop space – sliding the application to another application – click the application to open New Folder

13. Contacts are sorted, can change

Sort of way platform, the first number, then letters, then the standard way of sorting; the user can not set their own their own way

14. Contacts whether to support the group

Enter contacts - > select group, you can create groups, then will contact man to join the corresponding group

15. Contacts and SMS storage capacity limits the number of

Platform reason, contacts and SMS storage for no clear limit value, depending on the size of the current mobile phone memory space

16. How to set the SD card, personalized ring tones

In the SD card, are established "ringtones" (ringtones) "alarms" (alarm tone) "notifications" (SMS notification tone), the ring tones into a different folder, the phone can be automatically identified.

17. How to sync the phone contacts to the original

Use Bluetooth the way, the two cellphone, sync contacts;

18. How to use the access Wifi (WLAN)

Wifi signal at the scene to ensure that the premise of the specific see "Wifi function"

19. How to Find Contact

Into the contact interface, select the "Search" menu, you can search for contacts, you can use the first letter of query letters;

20. How do I delete the downloaded software

"Settings" - ""Manage app"- "Select the application to be deleted

21. How to view mobile phone version information

"Settings" - "" About phone "mobile phone version information can be obtained, including the Android version, Linux version, software version, hardware version, etc.

22. How do I copy SIM card contact information

Into the Contacts application, click the menu button, select "Import Contacts", then you can see the SIM card contacts, if only to import one, you can click an item. If all the import needs to long press the menu key, select Import to import all.

23. Why the message has a different time and date display

Message displayed on the principle that the display of the day, time and date have shown that non-day

24. Whether to support the Java

Due to platform reason, it does not support Java. If you need to install third-party Java applications, you need to install the Java runtime environment.

25. How to open developer options

Enter the Settings -- the about phone -- click the Build number four times, system will be generated developer options

26. Gestures

If the phone is not turned unlock pattern:

1. When you double-click on the screen, you can light up the screen
2. When the slide to the left of the screen, you can receive information directly into the interface
3. When you slide the screen to the right, you go directly dial interface
4. When you slide up the screen, you can go directly to the camera interface
5. When you slide down the screen, you go directly to MP3 player interface

If the phone is turned unlock pattern:

1. Double-click the screen lights up, directly into the unlock screen
2. Directly into the left slide to unlock screen, then manually enter the unlock received information interface
3. Slide to unlock directly into the interface, and then manually enter the dialing interface solution
4. Slide up to unlock directly into the interface, and then manually enter the camera interface solution
5. Slide down directly into the unlock screen, then manually enter the MP3 player interface solution

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This Mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: M488 (FCC ID: 2AIMEM488) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the **ear** is 0.98W/kg and when properly worn on the **body** is 1.03W/kg. This device was tested for typical body-worn operations with the back of the handset kept **10mm** from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a **10mm** separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **1.5 cm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.