



## **X301 “Wind 3G” User Manual**

---

## CONTENTS

Intro.....	3
Introduction phone keys .....	3
Widget Introduction .....	3
Function Information .....	4
Contact Features .....	7
Call History Features .....	9
Paste the text / copy Features.....	11
E-mail Features .....	11
Desktop Features .....	13
Delete the desktop icon.....	17
Music Function.....	17
FM function.....	18
Bluetooth Function .....	20
Wifi Features .....	20
Flight mode Function .....	21
Black unlock .....	22
Restore to factory default.....	22
Storage Settings .....	23
English language switching phone .....	24
Replacement mobile phone input method.....	25
Introduce cross-screen display .....	25
Browser Features .....	26

### Q A 28

1. How to turn off the software running in the background too much .....	28
2. How to quickly set up Email .....	28
3. How do I view the capacity of SD card case .....	28
4. How to save electricity .....	28
5. How lock screen, to prevent others from using .....	29
6. Why does not the USB data cable links your computer .....	29
7. How to install a program on a non-Android Market.....	29
8. In browsing the web or other applications, how to switch to other applications .....	29
9. How to enter the silent mode quickly .....	29
10. How to forward SMS / MMS.....	29
11. how to paste and copy text .....	29

---

## Introduction

### Introduction phone keys

Menu button: Click on the program display the corresponding menu item, the user can choose the corresponding sub-menu functions;

Home button: Click on the background into the current application will, and enter the main interface; Note that using this key will not really exit the application, the application will continue to run in the background;



Back button: Click to fall back to previous step of the operation of the interface;

### Introduction widgets

1, Add widgets to the main screen: in the idle interface -> Long press the main screen to add widget interface, Long press a widget to add to the standby interface or directly drag the widget to the target page.




2, Change the position of widgets: in the main interface, Long press a widget, sliding the widget can change the position of the widget in the main screen

3. Delete widgets: in the main interface, Long press a widget, the top of the main screen will be delete ", sliding the widget to delete , when there is red ", can let go, the widget is deleted or we can Press the small icon activates delete state, then Click on the small icon delete icon top left corner.





## Function Information

To sort the information by contacts, the conversational arrangement, user understanding of the history of the entire communication information, information sorted according to first contacts, including contact name for the first numbers, then letters (A-Z)




## Changing SMS tone


Access the information interface - "click the menu button, select "Settings" function - " Select "Select Ringtone"function;





## View sender information

Access to the information screen - "Select the message - " click  -


"click,can view the sender information






### Forwards

Access to the information screen - "Select the message - " Long press the Information, there shortcut keys - "select"Forward "function




### View information details

Access to the information screen- "Select the message-" Long press the Information, there shortcut keys -"select View details "function



Delete information session specific information on a particular  
Access to the information screen - "Select the message - " Long press and  
Information, there shortcut keys - "select "Delete "function




## Contact Features

contacts groups, contacts and favorites feature;


Book description

By the first number, then sort the way English characters (A-Z)



### Favorites Introduction

Included collection of contacts, and users often call the recent contact information, part of the overall fabric Top of the contact information for the user collection, lower often call into the system default contact information;




Contact Search

Into the contact interface - "click  button

Search supported by the first letter and the entire search string







Import contact information methods using Bluetooth to achieve data synchronization phone and the original binding, using Bluetooth to achieve synchronization of contacts;

### **Call History Features**

One by one to delete call records  
Enter the call log interface - "Click the menu button –Select the delete Function- " Choose the delete call records- click ok but t on




Contact information stored call records

Enter the call log screen - "Select the Save call log - " click- "select "Add to Contacts "feature

Or directly into the call log entry, -click  button -select "Add to Contacts


"feature



---

## Paste the text / copy Features

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All", "paste All"



## E-mail Features

Configuring mail account

Enter the Program Group screen - "Select"Email"application -"Enter e-mail address and password

If the system automatically recognizes the mailbox information, will automatically configure; if the system does not recognize, will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.


Gmail For example:

E-mail Address: [jondoe@gmail.com](mailto:jondoe@gmail.com)

Password: jondoe01


Configure multiple email accounts

Enter the Program Group screen - "Select"Email"application -" Click on the menu button-select setting function -select "Add Account"feature



### Delete an email account


Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select the "Remove Account"function



### Delete account

### Email check frequency setting


Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select Sync frequency "function



## Desktop Features

The common features into the desktop

Interface into the program group - "Select the desktop into the application  
-"long by application, the application will be placed to the desktop;





---

## Wallpapers

In the desktop space – Then Click on the menu button, select wallpaper option


## Application Packet

In the desktop space – sliding the application to another application – click the application to open New Folder




## Change the folder name

Open the folder on the desktop - " click Input box - Rename Folder



### Change wallpaper

Slide it to the edit control page, choose the wallpaper option,



### Add a shortcut to the desktop

Slide it to the edit control page, choose the add option, The Add screen, click the application icon you want to the target page



**Add contacts to your desktop**


In the widgets space -long press the contact widget -" choose a contact



**Add URL to the desktop**

In the widgets space -long press the Bookmark widget -" choose a bookmark





## Delete the desktop icon


Slide it to the edit control page, choose the arrange option, then the shortcuts converted to delete state, which you want to delete, click on the upper left corner of the delete icon



## Music Function


Play music

Music player into the main interface, select the song you want to play,



### Switch the display mode

The default is the grids shows that if you want to switch to the list shows, left to enter the Options menu, select list mode



### FM function



#### Open radio

Enter radio interface, click the switch button, turn on the radio



### Search Channel

Enter the Options menu, select the search channel, enter the search channel interface





### Switch to Speaker

FM player interface, enter the Options menu, choose speakers play



### Bluetooth Function


Select "Settings" -" Select "Bluetooth"function,



### Wifi Features


Select "Settings"- "Select Wi-Fi"- click "  ", select the desired access

APN




## Flight mode Function

Select "Settings"- "Select More"- " choose "Flight Mode"function




Or select the phone, "Off"button - "select the"Flight Mode "function





### Phone unlock

Select "Settings"->Select " security "-> Select the " Screen lock"-Pattern




### Restore to factory default

Select "Settings"->Select"Backup&reset "-> select "Factory data reset"



## Storage Settings



Select "Settings"->"Select"storage"



---



## English language switching phone

Select "Settings"- "Language & input "- Select " Language ", select English or other



## Input set

Select "Settings"- " Language & input "-click  but t on






---


## Replacement mobile phone input method

Select "Settings"- " Language & input "-Default



## Introduce cross-screen display

Select "Settings"-""Display "- "Check"Auto- rotate screen, " according to the phone automatically change the direction of rotation



---


## Browser Features

Visit the website

Browser - "Click url input area "-" Enter the URL of web browsing-click




but t on




Download Web page images or other objects

Browser - "browse the web, long press on the picture, there shortcut keys, choose "Save Image "function



Browser settings / search page

Browser - "browse the web" - "click "menu button", -select settings / find on page



---

## Q / A

### **1. How to turn off the software running in the background too much**

Download Advanced Task Manager Advanced Task Manager and select install, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, To free up memory space, reducing the CPU's operation long pressure, increase speed, to extend the purpose of standby time.

### **2. How to quickly set up Email**

In the Android system, can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password, if not automatically fit in the mailbox, the mailbox will be required by user Server information. See details in front of the "E-mail Features"section.

### **3. How do I view the capacity of an SD card**

Select the "Settings"-Select Storage -select "SD card and phone memory", will see the current SD card capacity information phone

### **4. How to save electricity**

First, reduce the screen brightness can be used in peacetime by reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;

Close GPS global positioning, in the "Settings"and select" location services" -uncheck the following "Enable GPS satellite set" can be;

Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;

Usually close calls and text messages to remind vibration;

---

## **5. How to lock screen phone**

In the "Settings", select " Security "and then select "screen lock""pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

## **6. Why is the USB data link not connecting to your computer**

Confirmed in the phone's "Settings"-""Developer options"- " in the "USB debugging"functionality check; also installed the correct USB driver

## **7. How to install a non-Android Market app**

Select "Settings"-"" Security ", the"unknown source "function check

## **8. In browsing the web or other applications, how do i switch to other applications**

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

## **9. How do I choose silent mode quickly**

In addition to continuing foreign long press the volume down key,and directly Into the status bar select the silent mode.

## **10. How to forward SMS / MMS**

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

## **11. How to paste and copy text**

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All" ,"paste All"

---

### **FCC RF Exposure Information and Statement**

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: FCC ID: 2ACLMX301WB has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.72W/kg and when properly worn on the body is 0.71 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar Accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed

---

to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The Wind 3G X301 complies with FCC guidelines and regulations under certification number 2ACLMX301WB